RCD(ELCB) Tester **KEW 5410**



Simple to use. Operating voltage is up to 400V.

RCD(ELCB) Tester

Detecting the voltage to earth of Earth electrodes or Protective conductors during RCD test - when applying test currents - at measurement using EARTH in order to prevent electrical shocks caused by the damaged earth. Measurement will be ceased at AC50V

or more.

Dust- and Water-proof

Dust- and Water-proof construction (designed to IEC60529 IP54)

Backlight

Facilitating working at dimly illuminated locations.

Specifications

		v.E	v.4	v4 /0	ALITO DAMP(mA)
Range Rated Voltage		x5			
Test current		15/30/50/100mA 15/30/50/100/200/500mA 15/30/50/100/200/500mA			
Measuring range		Testing time 200ms	Testing time 2000ms	Testing time 2000ms	40%~110% of I Δ n (goes up by 5%) Testing time 300ms x 15steps
Accuracy	Trip Time Test Current	±1%rdg±3dgt +2%~+8%dgt	±1%rdg±3dgt +2%~+8%dgt	±1%rdg±3dgt -8%~-2%dgt	Test Current at each step -4%~+4%
Voltage Me	asurement				
Measuring range		80V~450V(50/60Hz)			
Accuracy		±2%±4dgt			
Applicable Standard		IEC61010-1 Pollution degree 2 CAT.III 300V/ CAT.II 400V IEC61010-031 IEC61557-1,6 IEC60529(IP54)			
Display		1999 counts (3 1/2digits), Large LCD			
Operating temperature		0°C ~ 40°C, relative humidity 85% (no condensation)			
& humidity					
Storage temperature		-20°C ~ 60°C, relative humidity 85% (no condensation)			
& humidity					
Withstand Voltage		AC3700V / 1 min (between electrical circuit and enclosure)			
Insulation resistance		$50 \text{M}\Omega$ or more / 1000V (between electrical circuit and enclosure)			
Sleep Function		(1) Automatically enters Sleep mode in 3 min after the last switch operation (current consumption 75uA). This function doesn't work at voltage measurements. To exit from the Sleep mode, set the Function switch to OFF position once, and re-set it to the Range at which a measurement to be conducted. (2) Backlight turns off in 1 min after it lights up.			
Power Source		DC12V / Size AA battery R6P (SUM-3) ×8pcs			
Dimension		186(L)×167(W)×89(D)mm			
Weight		Approx. 965g (including batteries)			
Possible number		1200 times or more			
of Measurements		(measure every 30sec at x1/2 Range, I∆n =100mA)			
Accessories		7128 (Test lead) 7129 (Test lead with alligator clip) 8017 (Long pin) ×2			
		6017 (Long pin) x2	-		

Accessories

Test lead MODEL 7128





Test lead with alligator clip

MODEL 7129




Long pin

MODEL 8017


Neutral - Line

Connect the "PRIMARY" of the Connector Block to the Neutral of the power of RCD, and the "SEC-ONDARY" of the Connector Block to the Line of the load of RCD.




Line - Line

Connect the "PRIMARY" of the Connector Block to L2 of the power of RCD, and the "SECONDARY" of the Connector Block to L1 of the load of RCD.



Earth - Line

Connect the "PRIMARY" of the Connector Block to Earth, and the "SECONDARY" of the Connector Block to Line of the load of RCD.





Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

For inquires or orders:



http://www.kew-ltd.co.jp

No.5-20, Nakane 2-chome, Meguro-ku, Tokyo, 152-0031 Japan Phone:81-3-3723-0131 Fax:81-3-3723-0152 E-mail:info@kew-ltd.co.jp Factories:Uwajima & Ehime

